IBA-1, I-BEAM ADAPTER MOUNTING INSTRUCTIONS

IBA-1 Mounted on I-Beam or U-Channel

Positioning IBA-1 on I-Beam

NFPA-10 requires the <u>Bottom</u> of the fire extinguisher must be <u>at least 6 inches</u> above the floor.

The <u>Top</u> of fire extinguisher must be <u>NO higher than 60</u> inches above the floor.



Select approximate mounting position on beam or channel iron.

Do NOT tighten square-headed bolt yet.

Determine if extinguisher will be mounted on side of beam or face of beam.

Extinguisher mounted on Face of Beam



Mount Fire Extinguisher bracket on IBA-1 and tighten securely.

Extinguisher mounted on Side of Beam



Mount IBA-1 on I-Beam or channel iron and tighten square-headed bolt.

IBA-1 Mounted on Pallet Rack

Select mounting position on rack. Do NOT tighten square-headed bolt yet.



Determine if extinguisher will be mounted on side of rack as shown or front of rack (on top of "1/4 China" text).

Mount Fire Extinguisher bracket on IBA-1 and tighten securely.

Tighten square-headed bolt to secure IBA-1 on rack.

Bracket shown below mounted on end of rack with fender washer and 1/4"-20 nut on inside of Rack channel (IBA-1 not needed).

